




# MediaScreen 3 - Attaching Rubber End Caps



Remove cassette









Attach rubber end cap




Secure with the two screws


# MediaScreen 3 - Set-up Instructions




# Expand MediaScreen 3 - Attaching Rubber End Caps



Remove cassette



Attach rubber end cap



Secure with the two screws