




- Steps:
- 1) Attach front & back bases to the bottom of the stand with screws.
 - 2) Attach the clam shell to the stand with hex nuts.
 - 3) Insert iPad and feed wire through holes in stand.




When assembled

Optional Cover for Home Button



- 1) Remove foam lining from inside bottom of clamshell as shown.
 - 2) Attach Home Button Shield with double-sided tape to inside of clamshell, keeping top of shield flush with clamshell opening as shown.
- NOTE:** This is a permanent fix and can't be easily removed.







- Tools Required:
- 1) Philips Screwdriver (included)
 - 2) Pliers




WHEN DISASSEMBLING, TIGHTEN ALL SCREWS AND NUTS TO PREVENT LOSS DURING SHIPPING.

- Steps:
- 1) Attach front & back bases to the bottom of the stand with screws.
 - 2) Attach the clam shell to the stand with hex nuts.
 - 3) Insert iPad and feed wire through holes in stand.



When assembled

Optional Cover for Home Button



- 1) Remove foam lining from inside bottom of clamshell as shown.
 - 2) Attach Home Button Shield with double-sided tape to inside of clamshell, keeping top of shield flush with clamshell opening as shown.
- NOTE:** This is a permanent fix and can't be easily removed.



- Tools Required:
- 1) Philips Screwdriver (included)
 - 2) Pliers

WHEN DISASSEMBLING, TIGHTEN ALL SCREWS AND NUTS TO PREVENT LOSS DURING SHIPPING.