



BCL Universal Light Clip

Shown on an Xpressions SalesMate



1. Unpack your BCL light.
2. From the back of the frame find a vertical front scissor bar (A)
3. Squeeze the BCL Light base clip (B) to an open position
4. Release your squeeze on the the BCL Light base clip (B) so it returns to its closed position clamping onto the round vertical scissor bar (A)
5. The arm of the light should rest onto the hub as shown (C)
6. Repeat for remaining lights
7. Plug lights in

To Remove

1. Unplug all lights, wait for them to cool approximately 5 minutes.
2. Squeeze the BCL Light base clip (B) and lift away from the vertical scissor bar (A)
3. Release your squeeze on the BCL Light base clip (B)
4. Return lights to packaging