


sprint

Light Instructions




Sprint light pack includes:

- light (A)
- Light bulb (B)
- Light clip base (C)
- Cord with power pack plug (D)




Close up of Sprint banner stand from above right with graphic and light attached.

Top of Sprint banner stand mast without graphic shown.




Locate the black light / banner hardware clip (E) at the top of the Sprint banner stand mast. Find the upper top fins (E1). The light clip base (C) slides over the top fins (E1).




Position light clip base (C) level (see action 1). Slide clip base (C) onto the top fins (E1). Continue to slide the clip base (C) until the tracking fins (C1) are flush with the top fins (E1).

Top of Sprint banner stand mast with light clip shown



Light should now be attached to the top of the Sprint banner stand with the light clip (C) connected to the black light / banner hardware clip (E).

Top of Sprint banner stand mast with light attached.



Shown in full view from top left of the Sprint banner stand. Graphic is not shown installed. Graphic can be installed before or after the light. Only one light can be installed.



Sprint banner stand with light and graphic shown.